# ioLogik 2500 Series Quick Installation Guide

## Smart Remote I/O

Edition 6.0, January 2019

#### Technical Support Contact Information www.moxa.com/support

#### Moxa Americas:

Toll-free: 1-888-669-2872 Tel: 1-714-528-6777 Fax: 1-714-528-6778

#### Moxa Europe:

Tel: +49-89-3 70 03 99-0 Fax: +49-89-3 70 03 99-99

#### Moxa India:

Tel: +91-80-4172-9088 Fax: +91-80-4132-1045 <u>Moxa China (Shanghai office)</u>: Toll-free: 800-820-5036 Tel: +86-21-5258-9955 Fax: +86-21-5258-5505

#### Moxa Asia-Pacific:

Tel: +886-2-8919-1230 Fax: +886-2-8919-1231



© 2019 Moxa Inc. All rights reserved.

P/N: 1802025000033

# Package Checklist

- ioLogik 2500 series device
- 3-pin screw terminal block (for power input)
- 2 12-pin screw terminal blocks (for I/O)
- 2 8-pin RJ45-to-DB9 cables (CBL-RJ45M9-150)
- 1 antenna (only for wireless modules)
- Quick installation guide (printed)

# Appearance

## **Top View**



### Front View



# Physical Dimensions (unit = mm/inch)



# Specifications

Input Current	ioLogik 2512 Series:	254 mA @ 24 VDC,		
		529 mA @ 12 VDC,		
		133 mA @ 48 VDC		
	ioLogik 2512-GPRS Series:	416 mA @ 24 VDC		
	ioLogik 2512-HSPA Series:	352 mA @ 24 VDC,		
	_	728 mA @ 12 VDC,		
		187 mA @ 48 VDC		
	ioLogik 2512-WL1 Series:	354 mA @ 24 VDC,		
	_	735 mA @ 12 VDC,		
		189 mA @ 48 VDC		
	ioLogik 2542 Series:	281 mA @ 24 VDC,		
		589 mA @ 12 VDC,		
		144 mA @ 48 VDC		
	ioLogik 2542-GPRS Series:	494 mA @ 24 VDC		
	ioLogik 2542-HSPA Series:	311 mA @ 24 VDC,		
		649 mA @ 12 VDC,		
		166 mA @ 48 VDC		
	ioLogik 2542-WL1 Series:	380 mA @ 24 VDC,		
		797 mA @ 12 VDC,		
		203 mA @ 48 VDC		
Input Voltage	12 to 48 VDC			
Operating Temperature	Standard Models: -10 to 60°C (14 to 140°F)			
	Wide Temp. Models:			
	Ethernet: -40 to 75°C (-40 to 167°F)			
	Wireless: -30 to 70°C (-22 to 158°F)			
Storage Temperature	-40 to 85°C (-40 to 185°F)			

# Hardware Installation

# I/O Wiring



# Mounting

There are two sliders on the back of the unit for DIN rail and wall mounting.

### Mounting on a DIN rail

**Step 1:** If the spring-loaded bracket is locked in place, push the recessed button to release it.

**Step 2:** Insert the top of the rail into the upper lip of the attachment plate's slot.

Step 3: The attachment unit should now snap into place along the rail.

### Mounting on a wall (optional)

Step 1: Remove the DIN rail attachment plate.

 Step 2: Install the wall mounting kit to the back of the unit with M3 screws.
 6.0 mm

**Step 3:** Install the unit to the wall. The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown in the figure at the right.





# **Connecting the Power**

The ioLogik 2500 can receive power from a 12 to 48 VDC power source. Input power is applied to the positive (V+) and negative (V-) terminals on the connector.  $\underline{Power Supply} \blacklozenge$ 

For most applications, it is desirable to ground the system by connecting the system's power supply function ground (FG) to the power terminal's ground and the chassis ground (indicated with red markings in the image at the right).



**NOTE** For safety reasons, wires connecting the power supply should be *at least* 2 mm in diameter (e.g., 12 gauge wires).

### **Connecting to a Network**

The ioLogik 2500 has four built-in RJ45 Ethernet ports for connecting standard direct or crossover Ethernet cables.

LED I	ndicators
-------	-----------

Туре	Color	Description	
Power	Green	System power is ON	
(PWR)	Off	System power is OFF	
Ready (RDY)	Green	System ready	
	Red	System error	
	Off	System is not ready	
	Green	Ethernet connection enabled in 100 Mbps	
Ethernet Port (L1/L2/L3/L4)	Amber	Ethernet connection enabled in 10 Mbps	
	Flashing	Data transmitting	
	Off	Disconnected	
Serial Port (P1/P2)	Green	Тх	
	Amber	Rx	
	Flashing	Data transmitting	
	Off	Disconnected	
6.0	Green	SD card inserted	
50	Flashing	SD card being accessed	
I/O Channel	Green	Channel ON	
Status* Off		Channel OFF or No Counter/Pulse Signal	
\A/   :  - * *	Green	Cellular connection established	
W.Link**	Off	Off	
Signal Status**	Off	No signal, or No SIM card	
	1 LED	Weak or insufficient (SMS only)	
	2 LEDs	Average (good for cellular connections)	
	3 LEDs	Excellent signal	

\*Use the rotary switch to select which module's I/O channel status is displayed.

\*\*Wireless Modules Only.

# System Configuration

# **Configuration via IOxpress Utility**

The configuration of the ioLogik 2500 is mainly done with the IOxpress utility. IOxpress is a search utility that helps users locate an ioLogik 2500 device on the local network. The latest version of the utility can be downloaded from Moxa's website.

- Default IP Address: 192.168.127.253
- Default Subnet Mask: 255.255.0.0

**NOTE** Be sure to configure the host PC's IP address to the same subnet as the ioLogik 2500. For example, 192.168.127.250

### Load Factory Default Settings

There are three ways to restore the ioLogik 2500 to factory default settings.

- 1. Hold the RESET button for 5 seconds.
- 2. In the **IOxpress** utility, right-click on the ioLogik device to be reset and select **Reset to Default**.
- 3. Select Load Factory Default from the web console.



# WARNING

This equipment is intended to be used in Restricted Access Locations. External metal parts are hot! Before touching it, special attention or protection is necessary.

#### How to Download the Software

**Step 1**: Click on the following link to open the Support & Downloads search tool:

http://www.moxa.com/support/support\_home.aspx?isSearchShow=1

**Step 2:** Type the model name in the search box or select a product from the drop down box and then click **Search**.

Suppo	ort & Downloads		
	2512-HSPA	Search	
	OP		
	select product		
Please d	acose a model :		
Flease CI			
<ul> <li>ioLogik 25</li> </ul>	12-HSPA		

Step 3: Click the Software Packages link to download the latest software for the product.



# **ATEX Information**



- 1. Certificate number: DEMKO 15 ATEX 1603X
- 2. Certification string: Ex nA IIC T4 Gc
- Standards covered: EN 60079-0:2012+A11:2013, EN 60079-15:2010
- The equipment shall be installed in an enclosure that provides a degree of protection not less than IP54 in accordance with EN 60079-15 and accessible only by the use of a tool.
- 5. These products are for use in an area of not more than pollution degree 2 in accordance with EN 60664-1.